Potter PE-HSR — Quick Start Guide

Before Installation

• Confirm the PE-HSR is suitable for the intended indoor wall notification application.

• Disconnect power before making field wiring connections.

• Select the required candela and horn pattern according to the fire alarm system design.

Mounting

• Use the hinged mounting plate to support pre-wire and pre-test activities.

• Mount using a compatible single-gang box or approved Potter mounting arrangement.

• Keep the device accessible for inspection and servicing.

Wiring & Setup

• Connect wiring according to the applicable Potter installation instructions and the fire alarm system design.

• Use 12–18 AWG wiring as applicable to the installation.

• Set the required candela using the field-selectable setting.

• Select Continuous, T3 or T3/T4 horn pattern as required.

• Restore power and verify correct notification operation.

Testing

• Test the horn and strobe after installation.

• Verify synchronization where applicable.

• Confirm the selected candela setting and notification pattern meet the approved fire alarm design.

Safety

• Installation and testing should be performed by qualified fire alarm personnel in accordance with applicable codes and approved manufacturer instructions.